

# ENERGY PLUS

## ANALIZADOR DE RED MONOFÁSICO AC / DC (TRMS)

**V<sub>AC</sub>** **I<sub>DC</sub>** **COS $\phi$**  **V<sub>RMS</sub>**  
**W** **ARMS** **Hz** **Kw/h**

**SOFTWARE DE CONFIGURACIÓN GRATUITO**

**REGISTRADOR POR PENDRIVE**

**PROGRAMACIÓN POR CABLE**

Conexión microUSB

10A  
600Vac  
1000Vdc

ac ~  
dc =  
v, i  
RS485  
24V AC/DC

**ENTRADAS**

**AC/DC**

**..10A**

**..600VAC  
..1000VDC**

**SALIDAS**


**0-4/20mA**

**RS485**

**0/10V**

**RELÉ**

**ALIMENTACIÓN 24VDC-AC**



### CARACTERÍSTICAS

- Analizador de red monofásico AC/DC (TRMS) aislado.
- Convertidor de señal 1000VDC / 600VAC, 10A AC/DC. \*versión -L (100VDC / 60VAC).
- Medición de energía, tensión, intensidad, potencia, frecuencia, ..
- Configurable a través de USB, mediante software gratuito.
- Montaje en raíl DIN. Bornas enchufables.
- Alimentación 24VAC/DC.
- Salidas: analógica, de contacto de alarma y Modbus RS485.
- Registrador a través de memoria externa USB y posibilidad de descarga de datos en formato Excel.
- Reloj RTC integrado, con tiempo real.



# CONEXIONADO y CARACTERÍSTICAS

## ALIMENTACIÓN

DC	10.. 40Vdc
AC	20.. 28Vac

24VAC/DC

ALIMENTACIÓN

## AISLAMIENTO

ENTRADA
ALIMENTACIÓN
RS485 Y USB
SALIDA ANALÓGICA Y DIGITAL

4 vías


<b>INTENSIDAD</b>	Pasiva / Activa
0-4/20mA configurable	
Resistencia de carga máxima	<b>600Ohm</b>
<b>TENSIÓN</b>	
0/10V configurable	
Resistencia de carga mínima	<b>2KOhm</b>
<b>Relé de alarma</b>	
30V/50mA SPDT programable por software	
<b>RS485 Modbus</b>	
Configurable	

SALIDA




## INDICACIÓN DE LEDS

- POWER** Alimentación correcta
- FAIL** Fallo en el equipo
- Rx / Tx** Comunicación RS485 activa (led parpadeante)
- DOUT** Salida digital activa



MAYOR DE 10A /5



..10A (AC/DC)

ENTRADAS

## ENTRADA

TENSIÓN	versión -L
0.. 1000Vcc / ..600Vac	0.. 100Vcc / ..60Vac
INTENSIDAD	
0.. 10A (AC) / 0.. 10A (DC)	
mayores DE 10A (AC) TRAFO /5	

② ① UNIDOS INTERNAMENTE

## REGISTRADOR CON RELOJ



\* Pendrive opcional


Pendrive micro USB  
Exportación a Excel  
(formato .csv)

## AMBIENTALES


Temperatura de trabajo	- 15/+65°C
Temperatura de almacenamiento	- 40/+85°C

## FORMATO

Protección	IP20
Clase de combustibilidad Vo según UL94	
Caja Ergonómica. Montaje rápido rail EN50022	
Material Poliamida	PA6.6
Conexión: bornas enchufables por tornillo	
par de apriete tornillos(M3)	0,5Nm
Cable conexión: <2,5mm², 12AWG 250V/12A	
Peso	90 grs



SALIDAS




# INSTRUCTION MANUAL

## DESCRIPTION:

The ENERGY Plus is an isolated VOLTAGE and CURRENT converter and SINGLE PHASE NETWORK ANALYZER. The module has a programmable analog output (voltage or current) and a digital output (optomos). Thanks to the presence of the RS485 serial port can perform advanced functions such as I / O Module with Modbus RTU protocol. The ENERGY Plus behaves as a slave device by placing Current or Voltage Input, n°1 AO and n°1 DO.

## ELECTRICAL CONNECTIONS



### POWER SUPPLY:

10...40 Vdc or 20...28 Vac - Connectors 16 and 17, or by T-BUS connector (optional tool) on the base of the module (see the picture placed on the bottom of this page).






### VOLTAGE/CURRENT INPUT (DIRECT INSERTION):

the input Voltage (LINE) has to be connected on terminals 2 (+) and 8, the Load has to be connected on terminals 1 (+) and 6.

FOR VOLTAGE: up to 600 VAC, 1000 VDC (up to 60 VAC, 100 VDC for LV version).  
FOR CURRENT: up to 10 AAC/DC.

You can set the measurement range as per your need using the software or by RS485 using the modbus registers.

### INSERTION WITH EXTERNAL CURRENT TRANSFORMER (CT):



### ANALOG OUTPUT:

for Voltage analog output, connect terminals 31 and 29 (positive).

For ACTIVE current analog output, connect terminals 29 (positive) and 30. For PASSIVE current analog output, connect terminals 30 (positive) and 31. Analog output supply: 13 Vdc, max 30 mA.

### DIGITAL OUTPUT:

relay Output is an Optomos contact. Connection are with terminals 25 and 26. The contact can be used like an pulse output (you can set by FACILE the value of the pulse) or like Alarm contact (you can set the associated parameter by FACILE).

### SERIAL OUTPUT RS485:

available on connectors 32 (GND), 33 (B-), 34 (A+), or by T-BUS connector to be mounted on the module.

### T-BUS CONNECTION (OPTION), needs T-BUS connector:




it may be affixed to the accessory T-BUS based on the module to bring both power and serial communication. The number of modules supported by the bus is a function of the power supply used (check the absorption of the modules).

## SETTING THE DEVICE VIA SOFTWARE

The programming of the module may be performed in two different ways:

- via the free interface program through the microUSB port on the module or via RS485 connection;
- via the RS485 serial connection (from terminal or T-Bus).

The ENERGY Plus has two microprocessors, you can configure the module by connecting it to the USB port of your PC without the power lead, this is possible because the microprocessor that manages the configuration is powered directly from the USB port.




It is possible to use the program without connecting to the module, in this mode you can SAVE the configuration on your PC, which can then be sent to the ENERGY Plus at a later time.

### **SERIAL PORTS AVAILABLE:**

Check the available COM ports, press the UPDATE button. Your PC will assign a virtual COM connection with the ENERGY Plus. Press START CONNECTION WITH THE DEVICE. It will confirm you the connection was successful with the module. If the connection does not happen, please check the RS485 serial connection (A +, B-), the position of the dip-switches (switching off and on the device) and the COM generated automatically by the device. After connecting, you can proceed with the configuration of the device.



### **CURRENT RATIO, PULSE MANAGEMENT, FILTERS & CUT-OFF SETTINGS:**

This step on the software allow to define the Current Ratio by setting "CURRENT RATIO". The Pulse weight of the digital output can be setted by the WEIGHT IMPULSE FOR ENERGY CALC (Wh). RMS FILTER and AVERAGE FILTER COEFFICIENT are two different types of filters that allow you to introduce a delay of the answer in order to have more stability of the reading. CUT OFF settings: you can set the cut off values for VOLTAGE, CURRENT and POWER measurement. Under these value setted the measurement will be Zero.





## SETTING THE DEVICE VIA SOFTWARE



### FAIL MESSAGE / ANOMALY:

**FAIL HW:** problems in the measurement chain (electrical connections, microprocessor that manages the measurement, sensor disconnected or faulty).

**FAIL LOG:** problem on recording data (without the availability of stick usb memory stick usb not recognized).

**FAIL RTC:** problem on backup battery (dead or defective).

**FAIL EEPROM:** problem microprocessor configuration (not calibrated module, takes no configuration).

### MODBUS COMUNICATION:

This is the last window of the device configuration. The left column contains the parameters to be set for the communication speed BAUDRATE (from 1200 to 115200), the PARITY (None, Odd, Even), the STOP BIT (1 or 2), the Modbus address to be assigned to the device. You do not need to configure these parameters for the use of the module with digital / analog output. It is possible to use the module with RS485 serial output with Modbus output analog and digital simultaneously.

### LOGGING :

On the right side of the window you can enable the feature LOG for the acquisition of data on usb pendrive. You can name the log file by associating the extension .Xls, .Xlsx, .Csv, .Txt, .Dat, .Logs. The default file is in text format. The minimum sampling time is 1 second, the maximum is about 18 hours.


**ANALOG OUTPUT:** the first drop-down menu in the upper left allow you to associate the analog output to a single selectable **Vrms, Irms, Active Power, Reactive Power, Apparent Power, Cosφ, Frequency**. The mode of the analog output is VOLTAGE or CURRENT. The ENERGY Plus as the ability to scale the input and output as required, then select the measurement range of input (INPUT BEGIN SCALE and INPUT END SCALE) to assign to the analog output signal (OUTPUT BEGIN SCALE and OUTPUT END SCALE). Depending on the choices made in the two menu will change the units of measurement values in the input and output. If you select the MANUAL CONTROL (via modbus), you can manage the module as if it were an AO (Analog Output), thus freeing the analog output from the input selected. The analog output will be handled via RS485 Modbus RTU (see register map).

**DIGITAL OUTPUT:** the digital output default set is NOT ACTIVE. If you want to ACTIVE the digital output please set it on the right window.

**ALLARM / FAIL ANALOG OUTPUT:** it is possible to use the analog output to control any supervening anomaly Hardware HW FAIL, FAIL RTC Real Time Clock anomaly that stores the date and time, FAIL EEPROM for the anomaly on the microprocessor, FAIL LOG if an anomaly occurred during data acquisition, UNDER RANGE scale of measurement set, OVER RANGE scale of measurement set. It is possible to select multiple items in the menu. In case of alarm the analog output will go to 21 mA or 10.5 V depending on the selection made in the previous window.

**ALARM WINDOW:** you can activate the ALARM functionality (in the gray box), on the digital output or on the analog output, or both simultaneously. In this window you can manage HOW and WHEN activate the alarm by selecting the options from the dropdown menu: MORE THAN A THRESHOLD, LESS THAN A THRESHOLD, NOT BETWEEN TWO THRESHOLD, BETWEEN TWO THRESHOLD. We therefore have the possibility to insert the values of THRESHOLD and the value of HYSTERESIS. In the case where it is selected the value of a **Higher threshold** when the signal falls below, the alarm switched off at the threshold value minus the value of hysteresis. In the event that you have chosen the value of a **Minor threshold**, when the value exceeds the threshold plus the hysteresis value, the alarm is deactivated. In the case where it is selected **between two thresholds**, the hysteresis is external. In case you have selected **Not included between two thresholds**, the hysteresis is internal.

**ALARM / FAIL DIGITAL OUTPUT:** it is possible to use the digital output to control any supervening anomaly Hardware HW FAIL, FAIL RTC Real Time Clock anomaly that stores the date and time, FAIL EEPROM for the anomaly on the microprocessor, FAIL LOG if an anomaly occurred during data acquisition, UNDER RANGE scale of measurement set, OVER RANGE scale of measurement set. It is possible to select multiple items in the menu. By clicking on the "ENABLE ENERGY PULSE" is enabled the pulse. STATE DIGITAL ALARM / FAIL allows you to define the status of contact in case of alarm (NOT ACTIVE or ACTIVE).



## DATALOGGER

Serial Number	Data (yyyy-mm-dd) & Time	Status ID	Vpk	Ipk	Vrms	Irms	P	Q	S	Cosφ	Freq Total	Energy	Energy +	Energy -	Output Value	Output Type
12345678	2015/03/12-14-23-25	0	270	0	123		85,7			0,91	52	21	0			
12345678	2015/03/12-14-23-26	0	270	0	123		88,3			0,92	52,6	21	0			
12345678	2015/03/12-14-23-27	0	273	0	123		87,8			0,92	52,4	21	0			
12345678	2015/03/12-14-23-28	0	273	0	123		88,1			0,93	52,1	21	0			

The ENERGY Plus provides, on a local memory type PEN DRIVE USB (USB KEY) connected to the module via the microusb port, a series of information concerning the operation of the module, alarm status, type of input, the output type, the reading of the measured data, the measure of the output value from the module.


For each row correspond to a precise time reference. The module is equipped with an RTC Real Time Clock powered by a backup battery that lets you record data with YEAR / MONTH / DAY / HOUR-MIN-SEC.

The first number listed is the **SERIAL NUMBER** of the module, which allows it to be uniquely identified.

The second column give you information about: **DATE** (YEAR / MONTH / DAY / HOUR-MIN-SEC).

It is then reported the **STATUS ID** (Registry STATE) in binary mode to 16 bit. The binary number corresponds to the Modbus register 40005 that represents the state of the machine (Status: bit 0 = fail global, bit 1 = alarm, bit 2 = over range, bit 3 = under range, bit 4 = ?, bit 5 = dout status, bit 6 = fail hw, bit 7 = fail log, bit 8 = fail rtc, bit 9 = fail eeprom).

The following columns are **Vpk**, **Ipk**, **Vrms**, **Irms**, **Active Power (P)**, **Reactive Power (Q)**, **Apparent Power (S)**, **Cosφ**, **Frequency**, **Energy Total**, **Energy +**, **Energy -**, **Output Value**, **Output type** ( bit 0=Voltage/Current, bit 1-4=input Vrms, Irms, Active Power, Reactive Power, Apparent Power, Cosφ, Frequency, bit 5 = fail ur, bit 6 = fail or, bit 7 = fail hw, bit 8 = fail log, bit 9 = fail rtc, bit 10 = fail eeprom, bit 11 = fail alarm, bit 12-13 = 1 threshold over/1 threshold min/2 thresholds external/2 threshold internal, bit 14 = Manual mode), this value follows the setting made via software or via RS485.





### LIVE DATA USING SOFTWARE

once confirmed the configuration, the software allow you to see the data reading by the device directly. Please remind that you have to supply the device by external power supply .

### HOW TO IMPORT LOG DATA FROM EXCEL VERSION BEFORE 2003:


it's possible to import the data stored on the USB Memory Stick at any time (even if the log is not finished). Once you open the file with Excel (or Open Office), you will have to act on the functionality of the program for wrapping the data as described above. To do this, you can perform the following steps: select the first column, go to the option data, click on TEXT COLUMN, then choose the option that provides for the separation of the data by tabs or commas, the next step endorse the option POINT and COMMA.



The screenshot shows the Excel spreadsheet with the imported data. The data is organized into columns A through I, with rows representing individual data points. The first column (A) contains the serial number, and the subsequent columns contain the date, time, and various measurement values.

	A	B	C	D	E	F	G	H	I
1	12345678	2014/03/1	0	27.36	0	0	10000	359	
2	12345678	2014/03/1	0	27.36	0	0	10000	359	
3	12345678	2014/03/1	0	27.36	0	0	10000	359	
4	12345678	2014/03/1	0	27.36	0	0	10000	359	
5	12345678	2014/03/1	0	27.36	0	0	10000	359	
6	12345678	2014/03/1	0	27.5	0	0	10000	361	
7	12345678	2014/03/1	0	27.5	0	0	10000	361	
8	12345678	2014/03/1	0	27.5	0	0	10000	361	
9	12345678	2014/03/1	0	27.5	0	0	10000	361	
10	12345678	2014/03/1	0	27.5	0	0	10000	361	
11	12345678	2014/03/1	0	27.5	0	0	10000	361	
12	12345678	2014/03/1	0	27.36	0	0	10000	359	
13	12345678	2014/03/1	0	27.36	0	0	10000	359	

## QUICK GUIDE



### MODBUS ADDRESS CONFIGURATION AND BAUD RATE BY DIP-SWITCH

Through the dip-switch on the front panel of the module, you can change the Modbus address and baud rate. In the case in which all the dip switches are set to zero, the module will take the calibration from EEPROM, otherwise it will take parameters from a dip-switch. In order to assign addresses more than 62 assignments you need to take advantage of the interface software. In order to assign values of baud rates different from those selectable dip you should take advantage of the interface software.. For changing the addresses and the baud rate it can also be done by writing directly on the related registers.

### POWER SUPPLY

10...40 Vdc or 20...28 Vac - Connectors 16 and 17, or by T-BUS connector (optional tool) on the base of the module.

### POWER SUPPLY by T-BUS CONNECTION (T-BUS connector required):

it is possible to mount the accessory T-BUS to carry both power and serial communication. The number of modules supported by the function of the power supply bus is used (check the absorption of the modules).

### INTERFACE PROGRAM

It is the configuration software for ENERGY Plus module. The software is free and downloadable from the website . To communicate with the module you have to connect via USB port directly on your PC. You can configure the module via RS485 using the registers' map on the website.

### LEDS - FRONT SIGNALS:

**Power:** power presence on the device.  
**Fail:** presence of a failure/error on the device. It is activated in the case have been activated by FAIL messages on software. One or more events FAIL are active.  
**Rx, Tx:** the module is communicating via RS485 (LED blinking).  
**Dout:** digital output active.

### MOUNTING INSTRUCTIONS:

To mount the card on DIN rail, we recommend to place the top of the form on the edge of the bar omega, then pushing the bottom until it clicks. The module is equipped with a slider fastening that will be pushed forward in order to ensure the perfect fastening of the module on the bar.

**NOTE:** through the hole on the case of ENERGY Plus (shown in the figure), you can access an internal DIP SWITCH. Turning up the "DIP 1" you can activate the dynamic terminating of the Modbus.





# Modbus Registers Map

Register Name	Comment	Register Type	R/W	Default Value	Range	Modbus Address
<b>Machine ID</b>	Machine ID (1)	Unsigned short	R	3		<b>40001</b>
<b>FW version</b>	Firmware version (0)	Unsigned short	R			<b>40002</b>
<b>STATUS</b>	Status : bit 0 = fail global, bit 1 = alarm, bit 2 = overrange, bit 3 = underrange, bit 4= ?, bit 5=dout status, bit 6 = fail hw, bit 7=fail log, bit 8=fail rtc, bit 9=fail eeprom	Unsigned short	R/W		0...65535	<b>40005</b>
<b>Output Value</b>	mV or uA	Unsigned short	R/W		0...20000	<b>40006</b>
<b>Digital Output</b>	bit 0=disabled/enabled	Unsigned short	R/W	0		<b>40007</b>
<b>Dip switch status</b>	bit 0-7=dip switch status, pos 1=bit 7,..., pos 8=bit 0	Unsigned short	R/W			<b>40008</b>
<b>Vrms</b>	Voltage measurement rms (V)	Float (MSW)	R/W		0...10000	<b>40009</b> <b>40010</b>
<b>Irms</b>	Current measurement rms (mA)	Float (MSW)	R/W		0...14000	<b>40011</b> <b>40012</b>
<b>P</b>	Active Power Measurement (W)	Float (MSW)	R			<b>40013</b> <b>40014</b>
<b>Q</b>	Reactive Power Measurement (VAR)	Float (MSW)	R			<b>40015</b> <b>40016</b>
<b>S</b>	Apparent Power Measurement (VA)	Float (MSW)	R			<b>40017</b> <b>40018</b>
<b>Cosφ</b>	Cosφ Measurement	Float (MSW)	R		0...1	<b>40019</b> <b>40020</b>
<b>Frequency</b>	Frequency Measurement (Hz)	Float (MSW)	R			<b>40021</b> <b>40022</b>
<b>THD</b>	THD Measurement	Float (MSW)	R			<b>40023</b> <b>40024</b>
<b>Energy</b>	Totale Energy Measurement (Wh)	Float (MSW)	R/W			<b>40025</b> <b>40026</b>
<b>Energy positive</b>	Only positive Energy Measurement (Wh)	Float (MSW)	R/W			<b>40027</b> <b>40028</b>
<b>Energy negative</b>	Only negative Energy Measurement (Wh)	Float (MSW)	R/W			<b>40029</b> <b>40030</b>
<b>V peak</b>	Instantaneous Voltage Peak (V)	Float (MSW)	R/W			<b>40031</b> <b>40032</b>
<b>I peak</b>	Instantaneous Current Peak (mA)	Float (MSW)	R/W			<b>40033</b> <b>40034</b>
<b>V MAX</b>	Max RMS Voltage (V)	Float (MSW)	R/W			<b>40035</b> <b>40036</b>
<b>V min</b>	Min RMS Voltage (V)	Float (MSW)	R/W			<b>40037</b> <b>40038</b>
<b>I MAX</b>	Max RMS Current (mA)	Float (MSW)	R/W			<b>40039</b> <b>40040</b>
<b>I min</b>	Min RMS Current (mA)	Float (MSW)	R/W			<b>40041</b> <b>40042</b>
<b>P MAX</b>	Max RMS Active Power (W)	Float (MSW)	R/W			<b>40043</b> <b>40044</b>
<b>P min</b>	Min RMS Active Power (W)	Float (MSW)	R/W			<b>40045</b> <b>40046</b>
<b>Q MAX</b>	Max Reactive Power (VAR)	Float (MSW)	R/W			<b>40047</b> <b>40048</b>
<b>Q min</b>	Min Reactive Power (VAR)	Float (MSW )	R/W			<b>40049</b> <b>40050</b>
<b>S MAX</b>	Max Apparent Power (VA)	Float (MSW )	R/W			<b>40051</b> <b>40052</b>
<b>S min</b>	Min Apparent Power (VA)	Float (MSW )	R/W			<b>40053</b> <b>40054</b>
<b>Cosφ MAX</b>	Max Cosφ	Float (MSW )	R/W			<b>40055</b> <b>40056</b>



## Modbus Register Map

## Modbus Registers Map

Register Name		Comment	Register Type	R/W	Default Value	Range	Modbus Address
Cosφ min	Min Cosφ	Float (MSW )	R/W				40057
							40058
Frequency MAX	Max Frequency (Hz)	Float (MSW )	R/W				40059
							40060
Frequency min	Min Frequency (Hz)	Float (MSW )	R/W				40061
							40062
THD MAX	Max THD	Float (MSW )	R/W				40063
							40064
THD min	Min THD	Float (MSW )	R/W				40065
							40066
Vavg	V average (V)	Float (MSW )	R				40067
Iavg	I average (mA)	Float (MSW )	R				40068
							40069
Totalizer	Total Pulse Dout	UINT 32 (MSW)	R				40070
							40071
data L	Calibration data L	UINT 16	R				40072
data M	Calibration data M	UINT 16	R				40073
data H	Calibration data H	UINT 16	R				40074
Output Analog mode	bit 0=Voltage/Current, bit 1-4=input Vrms,Irms, Active Power, Reactive Power, Apparent Power, cos (Φ), Frequency, bit 5 = fail ur, bit 6 = fail or, bit 7 = fail hw, bit 8 = fail log, bit 9 = fail rtc, bit 10 = fail eeprom, bit 11 = fail alarm, bit 12-13 = 1 threshold over/1threshold under/2thresholds external/2 thresholds internal , bit 14= Manual mode	UINT 16	R/W		0		40075
Current Ratio	Current Ratio	Float (MSW )	R/W		1		40101
							40102
Output Analog Input Begin Scale	Output Analog Input Begin Scale	Float (MSW )	R/W		0		40103
							40104
Output Analog Input End Scale	Output Analog Input End Scale	Float (MSW )	R/W		300		40105
							40106
Output Analog Begin Scale	Output Analog Begin Scale	UINT 16	R/w		0		40107
Output Analog End Scale	Output Analog End Scale	UINT 16	R/W		10		40108
Delta ENERGY	Delta Energy (Wh) per pulse (50ms)	Float (MSW )	R/W		10		40109
							40110
Digital Output	bit 0=default value, bit 1 = fail ur, bit 2 = fail or, bit 3 = fail hw, bit 4 = fail log, bit 5 = fail rtc, bit 6 = fail eeprom, bit 7 = fail alarm, bit 8-9 = manual/pulse/fail, bit 10=low/high	UINT 16	R/W		0		40111
ALARM LOW	Alarm Low Trip value	Float (MSW )	R/W		0		40112
							40113
ALARM HIGH	Alarm High Trip value	Float (MSW )	R/W		0		40114
							40115
ALARM HYSTERESIS	Alarm Hysteresis value	Float (MSW )	R/W		0		40116
							40117
Modbus Address + Parity + StopBits	MSB modbus address, bit 0-1 = parity none/odd/even, bit 2=stop bits 1/2	UINT 16	R/W		260		40118
Modbus Baudrate	value 0=1200,1=2400,2=4800,3=9600,4=19200,5=38400,6 =57600,7=115200	UINT 16	R/W		5		40119
Log Mode	bit 0=disabled/enabled	UINT 16	R/W		0		40120
Log Sample time	Log sample time (s)	UINT 16	R/W		0		40121
Log name	Log name (15caratteri MAX)	UINT 16	R/W				40122
Log name	Log name (15caratteri MAX)	UINT 16	R/W				40123
Log name	Log name (15caratteri MAX)	UINT 16	R/W				40124
Log name	Log name (15caratteri MAX)	UINT 16	R/W				40125
Log name	Log name (15caratteri MAX)	UINT 16	R/W				40126
Log name	Log name (15caratteri MAX)	UINT 16	R/W				40127
Log name	Log name (15caratteri MAX)	UINT 16	R/W				40128
Log name	Log name (15caratteri MAX)	UINT 16	R/W				40129
Log name	Log name (15caratteri MAX)	UINT 16	R/W				40130
RMS Filter	Coeff. Filter RMS (0.99990 – 0.99999)	Float (MSW )	R/W		0,99990		40131
							40132
Average measurement filter	Average measurement filter (0.99990 – 0.99999)	Float (MSW )	R/W		0,9990		40133
							40134

## Modbus Registers Map

Register Name	Comment	Register Type	R/W	Default Value	Range	Modbus Address
Cut off Voltage	Cut off Voltage (V)	Float (MSW )	R/W	0		40135
						40136
Cut off Current	Cut off Current (mA)	Float (MSW )	R/W	0		40137
						40138
Cut off P	Cut off P (W)	Float (MSW )	R/W	0		40139
						40140
Vrms SW	Vrms (V)	Float (LSW )	R			40201
						40202
Irms SW	Irms (mA)	Float (LSW )	R			40203
						40204
P SW	Active Power (W)	Float (LSW )	R			40205
						40206
Q SW	Reactive Power (VAR)	Float (LSW )	R			40207
						40208
S SW	Apparent Power (VA)	Float (LSW )	R			40209
						40210
Cosφ SW	Cosφ	Float (LSW )	R			40211
						40212
Frequency SW	Frequency (Hz)	Float (LSW )	R			40213
						40214
THD SW	THD	Float (LSW )	R			40215
						40216
TOTAL ENERGY SW	Total Energy (Wh)	Float (LSW )	R/W			40217
						40218
Positive Energy SW	Positive Energy (Wh)	Float (LSW )	R/W			40219
						40220
Negative Energy SW	Negative Energy (Wh)	Float (LSW )	R/W			40221
						40222
Vpeak SW	Vpk (V)	Float (LSW )	R/W			40223
						40224
Ipeak SW	Ipk (mA)	Float (LSW )	R/W			40225
						40226
Vrms MAX SW	Vrms MAX (V)	Float (LSW )	R/W			40227
						40228
Vrms min SW	Vrms MIN (V)	Float (LSW )	R/W			40229
						40230
Irms MAX SW	Irms MAX (A)	Float (LSW )	R/W			40231
						40232
Irms min SW	Irms MIN (mA)	Float (LSW)	R/W			40233
						40234
P MAX SW	Active Power MAX (W)	Float (LSW)	R/W			40235
						40236
P min SW	Active Power MIN (W)	Float (LSW)	R/W			40237
						40238
Q MAX SW	Reactive Power MAX (VAR)	Float (LSW)	R/W			40239
						40240
Q min SW	Reactive Power MIN (VAR)	Float (LSW)	R/W			40241
						40242
S MAX SW	Apparent Power MAX (VA)	Float (LSW)	R/W			40243
						40244
S min SW	Apparent Power MIN (VA)	Float (LSW)	R/W			40245
						40246
Cosφ MAX SW	Cosφ MAX	Float (LSW)	R/W			40247
						40248
Cosφ min SW	Cosφ min	Float (LSW)	R/W			40249
						40250
Frequency MAX SW	Frequency MAX (Hz)	Float (LSW)	R/W			40251
						40252
Frequency MIN SW	Frequency MIN (Hz)	Float (LSW)	R/W			40253
						40254

# Modbus Register Map

Register Name		Comment	Register Type	R/W	Default Value	Range	Modbus Address
THD MAX SW	THD MAX	Float (LSW)	R/W				40255
							40256
THD min SW	THD MIN	Float (LSW)	R/W				40257
							40258
Vrms x 100	Vrms (V) x 100	SIGNED LONG(MSW)	R				40301
							40302
Irms x 100	Irms (mA) x 100	SIGNED LONG(MSW)	R				40303
							40304
P x 100	Active Power (W) x 100	SIGNED LONG(MSW)	R				40305
							40306
Q x 100	Reactive Power (VAR) x 100	SIGNED LONG(MSW)	R				40307
							40308
S x 100	Apparent Power (VA) x 100	SIGNED LONG(MSW)	R				40309
							40310
Cosφ x 100	Cosφ x 100	SIGNED LONG(MSW)	R				40311
							40312
Frequency x 100	Frequency (Hz) x 100	SIGNED LONG(MSW)	R				40313
							40314
THD x 100	THD x 100	SIGNED LONG(MSW)	R				40315
							40316
ENERGY x 100	Energy (Wh) x 100	SIGNED LONG(MSW)	R/W				40317
							40318
Positive Energy x 100	Positive Energy (Wh) x 100	SIGNED LONG(MSW)	R/W				40319
							40320
Negative Energy x 100	Negative Energy (Wh) x 100	SIGNED LONG(MSW)	R/W				40321
							40322
V peak x 100	Vpk (V) x 100	SIGNED LONG(MSW)	R/W				40323
							40324
I peak x 100	Ipk (mA) x 100	SIGNED LONG(MSW)	R/W				40325
							40326
Vrms MAX x 100	Vrms MAX (V) x 100	SIGNED LONG(MSW)	R/W				40327
							40328
Vrms min x 100	Vrms MIN (V) x 100	SIGNED LONG(MSW)	R/W				40329
							40330
Irms MAX x 100	Irms MAX (mA) x 100	SIGNED LONG(MSW)	R/W				40331
							40332
Irms min x 100	Irms MIN (mA) x 100	SIGNED LONG(MSW)	R/W				40333
							40334
P MAX x 100	Active Power MAX (W) x 100	SIGNED LONG(MSW)	R/W				40335
							40336
P min x 100	Active Power MIN (W) x 100	SIGNED LONG(MSW)	R/W				40337
							40338
Q MAX x 100	Reactive Power MAX (VAR) x 100	SIGNED LONG(MSW)	R/W				40339
							40340
Q min x 100	Reactive Power MIN (VAR) x 100	SIGNED LONG(MSW)	R/W				40341
							40342
S MAX x 100	Apparent Power MAX (VA) x 100	SIGNED LONG(MSW)	R/W				40343
							40344
S min x 100	Apparent Power MIN (VA) x 100	SIGNED LONG(MSW)	R/W				40345
							40346
Cosφ MAX x 100	Cosφ MAX x 100	SIGNED LONG(MSW)	R/W				40347
							40348
Cosφ min x 100	Cosφ MIN x 100	SIGNED LONG(MSW)	R/W				40349
							40350
Frequency MAX x 100	Frequency MAX (Hz) x 100	SIGNED LONG(MSW)	R/W				40351
							40352
Frequency min x 100	Frequency MIN (Hz) x 100	SIGNED LONG(MSW)	R/W				40353
							40354



# Modbus Registers Map

Q

Register Name	Comment	Register Type	R/W	Default Value	Range	Modbus Address
THD MAX x 100	THD MAX x 100	SIGNED LONG(MSW)	R/W			40355
						40356
THD min x 100	THD MIN x 100	SIGNED LONG(MSW)	R/W			40357
						40358
RTC YEAR	RTC : year (2000-2099)	UINT16	R/W			41001
RTC MONTH	RTC : month (1-12)	UINT16	R/W			41002
RTC DAY	RTC : day month (1-31)	UINT16	R/W			41003
RTC HOUR	RTC : hour (0-23)	UINT16	R/W			41004
RTC MINUTE	RTC : minute (0-59)	UINT16	R/W			41005
RTC SEC	RTC : second (0-59)	UINT16	R/W			41006

## REMARKS:

- Modbus connections: A+ and B- as per Modbus RTU standards;
- Modbus Register reference: with reference to the logical address, for ex. 40010, corresponds to physical address n°9 as per Modbus RTU standard;
- Dip Switch Settings: the setting is not enabled if the first sixth dip-switches are set to 000000, the rest of dip-switch are disabled. All settings coming from EEPROM.
- Modbus functions supported: 3 (Read multiple registers), 6 (Write single), 16 (Write multiple).
- Any changes made by dip-switch required to switch off the power supply